

1 Slide frame pieces onto the bracket.

2 Repeat step 1 for all four corners, pushing the frame rails onto the brackets until they lock into place.

3

Using proper backing and cut out the dimensions as noted below for the 1x2, 1x4, 2x2 or 2x4 HPR luminaire. Install drywall frame kit in ceiling.

4 Fasten drywall frame kit to backing using a proper fastener through holes in the drywall frame kit.

5 Install luminaire - Refer to additional installation instructions.

6 Secure fixture to drywall frame kit.