## FINELITE® Better Lighting

## **HP-WG Wall Bracket Mount Spackle Flange** Installation Instructions

### Overview

### **NOTES**

- · All power connections should be installed according to local/national codes by a Certified Electrician.
- This installation requires **proper support** as each luminaire is being installed.
- · DO NOT attempt to join luminaires together on the floor. Damage may result when lifted.






Dimmina




Plug-Together



# **HP-WG Wall Bracket Mount Spackle Flange** Installation Instructions **Step 1** - Wall Rail Mounting & Location






	Height from Bottom of the Wall Rail	
Luminaire Depth	X (in)	
2"	Ceiling Height A.F.F. + 2-1/8	
4"	Ceiling Height A.F.F. + 4-1/8	
6"	Ceiling Height A.F.F + 6-1/8	

- NOTE: Tolerances on dimensions are ± 1/16"
- Use provided table to measure wall rail height and mark it on all walls.

\*A.F.F.: Above Finished Floor



• Use appropriate #10 screws to secure wall rails to wall studs.




### **Step 2** - Identification & Preparation



Flexible Mounting Plate

### A. Identify Luminaires





Starter B Company of the starter B Company of

- Identify all luminaires by their ID label that can be found on the box and inside the luminaire.
- **NOTE:** Exact location of labels in these areas may vary.
- · Remove all luminaires from their box.
- · Refer to Record Drawings that can be found in the hardware kit.

#### **Kitted Hardware**

- Finelite has provided items listed here, with their Finelite part numbers. These items can be found in separate boxes shipped with the luminaire.
- Account for all parts and set aside until they are needed.
- All other hardware needed for this installation will be by others.



#### #8-18 x 1/4" Screw

Part# 69026
Feed Locations & Options
p. 4, Step 3
Mounting Starter to Structure
p. 6-7, Step 4
Joining Luminaires
p. 8, Step 5
Closing Luminaires
p. 9, Step 6



### #10-32 Screw

Part# 94144 Feed Locations & Options p. 4, Step 3




Bottom-Up View

### **Cover Sleeve**

Part# 10719 Closing Luminaires p. 9, Step 6

# **HP-WG Wall Bracket Mount Spackle Flange** Installation Instructions **Step 3** - Feed Locations & Options





#8-18 x 1/4" Screw (provided)





© 2021 FINELITE, INC. ALL RIGHTS RESERVED. Form




### **Step 3** - Feed Locations & Options




### **Top Feed** Top View

<b>Luminaire Length</b>	C (in)
2'	5
3'	5
4'	12
8'	12




#### Top Feed Location (standard)

- · Use chart above to find measurement of C for feed location.
- NOTE: For tailored length luminaire power feed locations, contact factory.




Luminaire Depth	D (in)
2"	3-5/16
4"	5-5/16
6"	7-5/16




# **HP-WG Wall Bracket Mount Spackle Flange** Installation Instructions **Step 4** - Mounting Starter to Structure



A. Mount Luminaire Side View



B. Secure Luminaire Side View



- Make electrical connections according to feed location and options.
- · Mount starter luminaire to wall rail by ensuring wall bracket grabs top of wall rail.
- · Align end of starter luminaire to start of main wall rail.


- Secure starter luminaire to wall rail with #8-18 x 1/4" screw through wall bracket.
- If there is no joiner/ender, then tighten fully. PROCEED TO STEP 6.

#8-18 x 1/4" Screw (provided)


### **Step 5** - Joining Luminaires








- Mount joiner/ender luminaire to wall rail by ensuring wall bracket grabs top of wall rail.
- Align end of starter luminaire to start of main wall rail.



- Connect plug-together wiring.
- Slide joiner/ender luminaire over aligner plate on starter luminaire and align holes.
- Secure joiner/ender luminaire to aligner plate using #8-18 x 1/4" screws.






- Secure joiner/ender luminaire to wall rail with #8-18 x 1/4" screws through wall brackets.
- Repeat this step if you have a long run with additional luminaires on the same wall.



## **Step 6** - Closing Luminaires








Luminaire Depth	J (in)	K (in)
2"	6-5/8	5-1/8
4"	6-5/8	7-1/8
6"	6-5/8	9-1/8

- Provide appropriate support blocking for proper drywall installation using the table above.
- NOTE: Make sure to leave ample space around wiring conduit.



- Mount spackle flange to drywall ceiling using appropriate #10 screws.
- Install mud guard cardboard inserts to help prevent spackle and paint from getting into the luminaire.
- · Spackle to cover the flange.
- Perform all spackling and painting to walls and ceiling before removing mud guards.


**CONTINUED** 



# **HP-WG Wall Bracket Mount Spackle Flange** Installation Instructions **Step 6** - Closing Luminaires



C. Final Step - Install Cover Sleeve Side View



- 1. Hook back edge of cover sleeve over edge of carrier.
- 2. Snap front edge of cover sleeve in place along the whole length of the luminaire (about every 6").
- Once cover sleeve is in place, turn power on to luminaire.

