

## Download the FineTune® TCS Mobile App

### Connect to the space you want to modify

**Blink** A “Blink” button will flash the lights to confirm you are connecting to the right space.

Add the name of the space and choose from options below.

### Operational Hours / Sweeps

1. Apply operational hours to everyday or weekdays and weekends
2. Select an “enable On” time
3. Select an “Off” time
4. Press “Save” to complete

### Add Tunable Schedules

Select from Finelite’s factory designed schedules

**OR** customize your own:

1. Select a time
2. Choose a transition time
3. Select a CCT (2700K - 6500K)
4. Repeat and “Save” when complete


### Adjust System Settings

- Set High-End trim to all luminaires in a space
- Adjust Demand Response reduction level
- Select Occupancy functionality:
  - Auto On / Off (Default)
  - Manual On / Auto Off (Vacancy)
  - Set a Partial On (Auto On / Off only)
  - Set a Partial Off

**Note:** Custom settings and scheduling can be created On or Off site. These setting are saved and can easily be uploaded to other spaces.



FineTUNE TCS



FineTune® TCS App



iOS



ANDROID

(coming soon)



Bluetooth