

LED Module Replacement Instructions

- 1. Disconnect desk lamp from power supply
- 2. Rotate desk lamp head to face upward
- 3. Remove screw using #1 Phillips screwdriver and lift reflector
- 4. Disconnect cable from brown connector
- 5. Remove old LED module, leaving heat transfer layer in the head
- 6. Insert new LED module
- 7. Re-connect cable to brown connector on new LED module
- 8. Replace reflector and hand tighten screw
- 9. Connect desk lamp to power supply and test by turning on
- 10. Recycle old LED module at electronics recycling collection point or return to Finelite

