HO4 Driver Replacement Installation Instructions

Overview



NOTES

- · Ensure that reflectors do not get dirty or damaged.
- · All power connections should be installed according to local/national codes by a Certified Electrician.










Dimming



Installation




© 2021 FINELITE, INC. ALL RIGHTS RESERVED. Form - 98345 V2 EFFECTIVE DATE: 09/21


HO4 Driver Replacement Installation Instructions **Step 1** - Opening Luminaire

FINELITE® Better Lighting

A. Remove Reflector



- Turn power off to luminaire.
- CAUTION: Wear gloves to keep reflector surface clean.
- Remove reflector by carefully placing a flat edge (such as a clean putty knife) between the reflector and luminaire body.
- · Push slightly up, and angle out.



• Use putty knife to slip behind backplate edges and release backplates from clips (4 clips per backplate).


HO4 Driver Replacement Installation Instructions **Step 2** - Remove & Replace Driver


FINELITE® Better Lighting

Remove & Replace Driver


Standard


WIRING LEGEND		
Black	Hot	Line Voltage
White	Neutral	Line Voltage
Green	Ground	
Pink	Dimming	0-10V DC
Purple	Dimming	0-10V DC
•		





- · Disconnect electrical connections from driver.
- Release driver from luminaire body by removing mounting screws.
- Remove old driver and replace with new driver.
- · Replace mounting screws.
- Reconnect electrical connections to driver.





- Disconnect driver from driver harness.
- Disconnect electrical connections from driver.
- Release driver from luminaire body by removing mounting screws.
- · Remove old driver and replace with new driver.
- Replace mounting screws.
- · Reconnect electrical connections to driver.
- · Reconnect driver to driver harness.









HO4 Driver Replacement Installation Instructions **Step 3** - Closing Luminaire

FINELITE® Better Lighting

A. Replace Backplate



B. Final Step - Replace Reflector



- CAUTION: Wear gloves to keep reflector surface clean.
- Carefully replace reflector by squeezing sides and inserting into luminaire body.
- Ensure reflector is pulled down so that the bottom edges catch the groove of the support rail.
- NOTE: Reflectors installed in joiner and ender luminaires are 1/4" longer. When installing the reflectors, overlap the reflector of the previous luminaire section by 1/4".
- Turn power on to luminaires.

• Replace backplate by rotating back into luminaire body and snapping into clips.



© 2021 FINELITE, INC. ALL RIGHTS RESERVED. Form - 98345 V2 EFFECTIVE DATE: 09/2-