

Download the FineTune® TCS Mobile App

Connect to the space you want to modify

Blink A “Blink” button will flash the lights to confirm you are connecting to the right space.

Add the name of the space and choose from options below.

Operational Hours / Sweeps

1. Apply operational hours to everyday or weekdays and weekends
2. Select an “enable On” time
3. Select an “Off” time
4. Press “Save” to complete

Add Tunable Schedules

Select from Finelite’s factory designed schedules
OR customize your own:


1. Select a time
2. Choose a transition time
3. Select a CCT (2700K - 6500K)
4. Repeat and 'Save' when complete

Adjust System Settings

- Set High-End trim to all luminaires in a space
- Adjust Demand Response reduction level
- Select Occupancy functionality:
 - Auto On / Off (Default)
 - Manual On / Auto Off (Vacancy)
 - Set a Partial On (Auto On / Off only)
 - Set a Partial Off



FineTUNE TCS



FineTune® TCS App

Note: Custom settings and scheduling can be created On or Off site. These setting are saved and can easily be uploaded to other spaces.



iOS



ANDROID

(coming soon)



Bluetooth