Overview





- · All power connections should be installed according to local/national codes by a Certified Electrician.
- This installation requires proper support as each luminaire is being installed.
- DO NOT attempt to join luminaires together on the floor. Damage may result when lifted.



Access




0-10V

Dimming



Plug-Together



Step 3

Page 4

Mounting Starter to Structure

Page 6

Step 1 - Mounting & Suspension



Mounting Options


Drywall (C4) or other hard surfaces* - Wet Rated J-Box and Anchor Bolts

- Install wet rated J-Box and wet rated electrical conduit at feed locations.
- Install anchor bolts at mounting point locations.
- All anchor bolts are to be secured to structure, per local building codes.
- * Other hard surfaces include: wood, sheet metal panels, steel beams, concrete or masonry. Use hardware appropriate for each surface material type.

Suspension Locations

X = Suspension Dimensions

Refer to Record Drawings and building plans to determine exact mounting, suspension points, and power feed locations.








Step 2 - Identification & Preparation


FINELITE® Better Lighting

A. Identify Luminaires





- · Identify all luminaires by their ID label that can be found on the box, the diffuser and inside the luminaire.
- **NOTE:** Exact location of labels in these areas may vary.
- Remove all luminaires from their box.
- Refer to Record Drawings that can be found in the hardware kit.



- Set aside all diffusers to prevent from getting dirty or damaged.
- Ensure diffusers can be clearly identified back to its corresponding luminaire.

Kitted Hardware

- Finelite has provided items listed here, with their Finelite part numbers. These items can be found in separate boxes shipped with the luminaire.
- Account for all parts and set aside until they are needed.
- · All other hardware needed for this installation will be by others.



5" Canopy

5" Dual Feed Canopy

Part# 94145 **Mounting Starter to Structure** p. 4, Step 3 **Joining Luminaires** p. 5, Step 4



2" Drywall Support Canopy

Part# 94017 **Mounting Starter to Structure** p. 4, Step 3 **Joining Luminaires** p. 5, Step 4



Yoke Bracket Part# 43659

#10-32 x 5/8" Screw

Part# 94144 Securing Luminaire Joints p. 7, Step 6



Part# 43700

Mounting Starter to Structure p. 4, Step 3 Joining Luminaires p. 5, Step 4



Slip Ring w/ Set Screw

50" - Part# 94515-12 (Std.)

Mounting Starter to Structure

100" - Part# 94515-14

150" - Part# 94515-18

Joining Luminaires

Cable Bushing

Aircraft Cable

Part# 94014

p. 4, Step 3

p. 5, Step 4

Part# 94015 **Mounting Starter to Structure** p. 4, Step 3 **Joining Luminaires** p. 5, Step 4



Safety Crimp

Part# 94514 **Closing Luminaires** p. 8, Step 7



Diffuser Screw

HP-2 WL: #6-32 x 3/8" Screw - Part# 76404 HP-4 WL: #6-32 x 3/8" Screw - Part# 76404 HP-6 WL: #8-32 x 1/2" Screw - Part# 94298 **Identification & Preparation** p. 5, Step 2 Closing Luminaires p. 11, Step 7



Endcap Diffuser Cover Part# 43738

Closing Luminaires p. 8, Step 7



Joint Diffuser Cover

Part# 43741 **Closing Luminaires** p. 8, Step 7


Screw Cover

Part# 43637 Closing Luminaires p. 8, Step 7

Step 3 - Mounting Starter to Structure

FINELITE® Better Lighting


A. Mount Starter to Structure



- Slide slip ring onto bushing/cable assembly and thread onto mounting bolts. Secure slip ring with set screw at both mounting locations.
- Attach grippers onto threaded studs found on end plates of starter luminaire.
- While properly supporting luminaire, maneuver luminaire to ceiling.
- Turn the top grip on gripper counter clockwise to unlock.
- Depress the top of the gripper to feed the aircraft cable through.
- Turn the grip clockwise to lock aircraft cable.
- CRITICAL: Level luminaire section. If part of an independent run, PROCEED TO STEP 7



WIRING LEGEND		
Black	Hot	Line Voltage
White	Neutral	Line Voltage
Green	Ground	
Grey	Dimming	0-10V DC
Purple	Dimming	0-10V DC



• Feed power cord through the 5" canopy and connect wires inside the wet rated J-Box.



5" Canopy (provided)



2" Drywall Support Canopy (provided)



(provided)

Gripper (provided)




Slip Ring w/ Set Screw (provided)




© 2020 FINELITE, INC. ALL RIGHTS RESERVED. Form - 98438. V4 EFFECTIVE DATE: 09/09/2020


HP-4 Wet Location Direct Installation Instruction **Step 4** - Opening Luminaires







- NOTE: For independent luminaires, backplates do not need to be released.
- Release the backplates from clips by sliding the blade of a putty knife behind backplate edges.
- To use a flathead screwdriver, press end of screwdriver (from inside the luminaire) against the clip, until the backplate is released.



• Carefully rotate backplate out at the joint only and let them hang from luminaire body.




Step 5 - Joining Luminaires



A. Mount Joiner/Ender to Structure






- CRITICAL: If luminaire contains a sensor, refer to Sensor Addendum before joining luminaires.
- For the joiner/ender luminaire, slide canopy appropriate for electrical type onto mounting bolt.
- · Thread the bushing/cable assembly onto mounting bolt.
- Attach grippers onto threaded studs found on end plates of joiner/ender.
- While properly supporting luminaire, maneuver luminaire to ceiling.
- Turn the top grip on gripper counter clockwise to unlock.
- Depress the top of the gripper to feed the aircraft cable through.
- Turn the grip clockwise to lock aircraft cable.

B. Join Luminaires



Once luminaires are aligned together, joiner luminaire is not yet secure. Ensure it does not slide off as it rests on the starter luminaire.




- Align joiner/ender with aligner sleeves on starter and slide together. Be careful not to damage any wiring.
- · If necessary, lift both luminaires, then slide together.



5" Canopy (provided)



2" Drywall Support Canopy (provided)









Slip Ring w/ Set Screw (provided)


© 2020 FINELITE, INC. ALL RIGHTS RESERVED. Form - 98438. V4 EFFECTIVE DATE: 09/09/2020


Step 6 - Securing Luminaire Joints











- Before installing yoke brackets, ensure the joining ends of luminaires meet flush and square.
- CRITICAL: Ensure yoke brackets properly engage with aligner sleeves.
- Secure joint by threading (**but not yet tightening**) yoke screws through yoke brackets and into the aligner sleeves.
- Ensure all leveling has been performed.
- Tighten yoke screws¹ until joint seam of luminaires is closed.







Step 7 - Closing Luminaires

FINELITE® Better Lighting


A. Crimp Cables



- Ensure all leveling has been performed prior to applying safety crimp
- Loop aircraft cable through safety crimp.
- Crimp, then cut excess cable.



- NOTE: If your installation includes a battery backup, please see addendum (98333) that should be included with your kitting package.
- Reinstall any open backplates by rotating into luminaire body and snapping back into clips.
- Remove diffusers from protective plastic bag.
- CAUTION: Wear gloves to keep diffuser surface clean, take care to wipe off any water or condensation on diffusers before installing into luminaire.
- CRITICAL: Be sure to install correct diffuser to its corresponding luminaire ID.
- Install diffusers into luminaire body, ensuring they snap into place.



· Carefully line up endcap and joint diffuser covers.


Joint Diffuser Cover (provided)

Diffuser Screw (provided)


Screw Cover (provided)

- Secure using screws provided, place screw cover on end cap and joint diffuser cover. Ensure screw cover lays flat; if not, flip 180°.
- · Install all endcap and joint diffuser covers.
- Turn power on to luminaire.





Endcap Diffuser Cover (provided)



Joint Diffuser Cover (provided)



Diffuser Screw (provided)

